

Teebaud rug pad installation instructions

1. Remove the old rug.
2. Place The new rug in the room to confirm placement location.
3. Use painters tape to mark all four corners of the rug.
4. Remove the rug to set the pad.
5. Place Teebaud pad with the White side down and plastic side up. Leave plastic in place.
6. Place the rug over the plastic.
7. When the rug is in the correct position, roll one one side to the center to expose plastic.
8. Remove the exposed plastic to the rolled rug. Pro Tip: tease plastic a little bit at a time and keep the tugging or teasing motion parallel with the floor (do not pull up).
9. Cut the removed plastic off with scissors.
10. Roll the rug slowly over the newly exposed pad. Make sure there are no bubbles or wrinkles.
11. Repeat this process from the other side.

Tools needed:

- measuring tape
- painters tape
- sharp scissors